

Brand	Type	Code
A TREND	TV	1051
	DVD	2056
A.R. SYSTEM	TV	1052, 1061, 1091, 1173, 1233
AB SAT	SAT	4430, 4480
ACCENT	TV	1054, 1062, 1091, 1157
	VCR	2327, 2330
ACCESS MEDIA	SAT	4441, 4505
ACEC	see	PHILIPS
ACTION	TV	1157
ADB	SAT	4356
ADMIRAL	TV	1011, 1027, 1034, 1080, 1081, 1157, 1192, 1262, 1298
	VCR	2356
ADYSON	TV	1103, 1157, 1274, 1347
	VCR	2329, 2330
AEG	TV	1349
	DVD	2001, 2081
AEGYR	SAT	4411
AGASHI	TV	1051, 1052, 1091, 1157
	VCR	2330
	SAT	4413
AGB	see	SABA
AGEF	see	BRUNS
AIKO	TV	1157, 1210, 1231
AIM	TV	1052, 1053, 1054, 1079, 1132, 1160, 1233, 1258, 1274
	VCR	2349, 2350
	DVD	2034, 2040
AIOSTAY	TV	1012, 1120, 1157, 1347
	VCR	2307, 2327
AIWA	TV	1038, 1106, 1109, 1344
	VCR	2307, 2313, 2326, 2327, 2354, 2375, 2380
	DVD	2005, 2024, 2051, 2099
	COMBI	1106, 1344, 2327, 2331
	HIFI	3041, 3047
AKAI	TV	1003, 1007, 1010, 1012, 1014, 1019, 1031, 1035, 1051, 1052, 1072, 1075, 1077, 1091, 1109, 1132, 1134, 1138, 1140, 1141, 1144, 1154, 1157, 1160, 1162, 1172, 1184, 1190, 1201, 1203, 1204, 1210, 1211, 1231, 1274, 1349, 1351, 1415
	VCR	2302, 2304, 2310, 2314, 2326
	DVD	2001, 2038, 2039, 2070
	SAT	4341
	COMBI	1106, 1140
AKARI	TV	1321
AKI	TV	1051, 1231
AKIBA	TV	1210
	VCR	2330
AKIRA	TV	1051, 1054, 1062, 1158, 1190

Brand	Type	Code
AKITA	see	ORION
AKTRON	see	TOSHIBA
AKURA	TV	1031, 1032, 1035, 1049, 1051, 1052, 1061, 1062, 1091, 1145, 1157, 1206, 1210, 1349
	VCR	2326, 2330
ALBA	TV	1012, 1032, 1035, 1051, 1052, 1061, 1075, 1083, 1130, 1147, 1157, 1190, 1206, 1210, 1225, 1227
	VCR	1107, 2330, 2349, 2350, 2354, 2377
	SAT	4339, 4409, 4433, 4450, 4452, 4453
ALBIRAL	TV	1012, 1051, 1052, 1091, 1186, 1210, 1225, 1227, 1233
ALCO	DVD	2001
ALDES	SAT	4337, 4411, 4477
ALHORI	TV	1231
ALKOS	see	TOSHIBA
ALL TEL	DVD	2061, 2063, 2095
ALLANTIDE	SAT	4462
ALLORGAN	TV	1008, 1192, 1231
	VCR	1210, 2310, 2327
ALLSAT	SAT	4401, 4468
ALLSONIC	SAT	4477
ALLSTAR	TV	1052
	VCR	2340
ALTAI	SAT	4386
ALTEK	TV	1392
	DVD	2040
AMADEUS	TV	1228
AMCOL	VCR	2310
AMPERE	see	ARCON
AMPLIVISION	TV	1231, 1233
AMSTRAD	TV	1027, 1031, 1051, 1052, 1061, 1075, 1091, 1157, 1210
	VCR	2327, 2331
	DVD	2001, 2005, 2006, 2007, 2009, 2038, 2059, 2062, 2084
	SAT	4329, 4395, 4418, 4430, 4441, 4444
	COMBI	2327
AMWAY	VCR	2340
ANEX	TV	1051, 1052
ANGLO	TV	1091, 1157
	VCR	2327
ANIS	TV	1091, 1147, 1157
ANITECH	TV	1002, 1049, 1052, 1091, 1103, 1157, 1195, 1209, 1274
	VCR	1216, 2310, 2327, 2329, 2330, 2340, 2345
ANKARO	SAT	4350, 4420, 4460, 4477
ANNTRON	SAT	4409, 4490
ANSONIC	TV	1032, 1049, 1051, 1061, 1091, 1145, 1147, 1157, 1158, 1217
ANTECNO	TV	1210
APHEL S.	VCR	2327, 2345, 2354
APOLLO	SAT	4409
AQP	see	GRUNDIG
ARC EN CIEL	see	THOMSON

Brand	Type	Code
ARCAM	TV	1231
ARCELIK	TV	1012, 1039, 1051, 1052, 1093, 1101, 1145, 1147, 1158, 1173, 1180, 1198, 1203
ARCON	SAT	4331, 4418
ARDEM	TV	1147, 1158, 1203, 1287
ARENA	TV	1130
ARION	SAT	4353, 4507
ARISTONA	see	PHILIPS
ARMSTRONG	SAT	4413, 4468
ARNION	SAT	4303
ARPHONE	see	DESMET
ARTHUR M.	see	SALORA
ART-TECH	TV	1051, 1052, 1157, 1209
ASA	TV	1019, 1034, 1051, 1052, 1110, 1111, 1120, 1143, 1298
	VCR	2307, 2327, 2345
AS-BERG	TV	1049, 1052, 1190, 1195
ASHIN	SAT	4418
ASORA	TV	1091, 1157
ASSCOM	SAT	4390
AST	SAT	4355, 4481
ASTHON	see	EMERSON
ASTI	SAT	4378
ASTON	SAT	4334, 4391, 4401, 4419
ASTRA	TV	1052, 1075, 1157, 1274
	VCR	2327
	SAT	4355, 4394, 4436, 4490
ASTRO	SAT	4339, 4355, 4372, 4410, 4435
ASTRO SOUND	TV	1012, 1051, 1052, 1195, 1233
ASUKA	TV	1002, 1012, 1091, 1210, 1231
	VCR	2307, 2327, 2330, 2345
ATAKI	TV	1209
ATLANTIC	see	FORMENTI
ATLANTIS	SAT	4421
ATORI	TV	1157
AUDIO DYN.	VCR	2342
AUDIOLA	DVD	2064, 2065
AUDIOSONIC	TV	1003, 1012, 1026, 1046, 1051, 1052, 1091, 1113, 1130, 1145, 1147, 1157, 1158, 1160, 1184, 1195, 1203, 1209, 1210, 1219, 1225, 1227, 1231, 1258, 1287, 1347
	VCR	2307, 2327, 2330, 2345, 2349, 2353
	DVD	2039
	COMBI	1157, 2330
AUDIOSTAR	TV	1157, 1209, 1210
AUDIOTON	TV	1002, 1157, 1225, 1231
	VCR	2342
	SAT	4401
AURIGA	SAT	4356, 4411, 4464
AURORA	TV	1160, 1231, 1298
AUSIND	TV	1120
AUTHENTIC	VCR	2326

Brand	Type	Code
AUTOVOX	TV	1008, 1052, 1061, 1120, 1177, 1192, 1225, 1347
	VCR	2307, 2345
	DVD	2005
AWA	TV	1046, 1051, 1052, 1157, 1160, 1172, 1231
	VCR	2310
AWATRON	TV	1157
	VCR	2327
AXIS	SAT	4420
AXOSAT	SAT	4377, 4453
AXXENT	TV	1051
BAIRD	TV	1073, 1079, 1172, 1257
	VCR	2302, 2304, 2326, 2330, 2349, 2356, 2357
BANG & OLUFSEN	TV	1049, 1298, 1348
	VCR	2326, 2345
BARCO	TV	1277, 1298
BARCOM	TV	1274
	SAT	4350
BASIC LINE	TV	1003, 1012, 1032, 1051, 1052, 1061, 1157, 1158, 1160, 1203, 1209, 1210, 1287
	VCR	2330, 2349, 2354
BASTIDE	TV	1231
BAUER	TV	1002, 1051, 1240, 1258
	VCR	2345, 2362
BAUMATIC	TV	1091
BAUR	TV	1003, 1006, 1008, 1026, 1049, 1051, 1052, 1053, 1054, 1062, 1064, 1070, 1072, 1077, 1088, 1123, 1132, 1141, 1144, 1148, 1154, 1157, 1232, 1235, 1238, 1245, 1352
BAYSONIC	TV	1091
BAZIN	TV	1020, 1231
BEAULIEU	VCR	2345
BEC	SAT	4510
BEKNTTEKNIK	TV	1077, 1093, 1145
BEKO	TV	1012, 1039, 1051, 1052, 1061, 1068, 1093, 1101, 1145, 1147, 1158, 1180, 1198, 1203, 1232, 1287
BELSTAR	TV	1061, 1350
BEON	TV	1051, 1190
BEST	SAT	4350, 4420, 4477
BESTAR	TV	1002, 1039, 1049, 1051, 1061, 1075, 1145, 1147, 1157, 1350
	VCR	2349
BIAZET	TV	1021, 1051
BIFONIC	TV	1157, 1231
BIG BEN	DVD	1284
BIGSTON	TV	1091, 1157, 1160
BINATONE	TV	1231
BLACK DIAMOND	TV	1061
	VCR	2350
	DVD	2005

Brand	Type	Code
BLACK PANTHER	TV	1195
	VCR	2349
BLACKSTAR	TV	1210
BLACKTRON	TV	1210
BLACKWAY	TV	1141, 1210
BLAUPUNKT	TV	1046, 1125, 1132, 1133, 1141, 1144, 1148, 1152, 1154, 1173, 1211, 1220, 1239, 1240, 1244, 1262, 1265
	VCR	2310, 2323, 2333, 2343, 2344, 2347, 2362
	SAT	4435
BLAUSONIC	TV	1012, 1231
BLUE SKY	TV	1032, 1035, 1037, 1051, 1052, 1061, 1158, 1203, 1206, 1210, 1287, 1349
	VCR	2307
	DVD	2005, 2024, 2049, 2059, 2088
	COMBI	1106
BLUE STAR	TV	1012, 1034
	VCR	2329, 2330
BOCA	see	AMSTRAD
BONDSTEC	TV	1225
	VCR	2329, 2330
BOOTS	TV	1231
BOSCH	TV	1002, 1240
	VCR	2345, 2362
BOSTON	TV	1231, 1298
BRAIN WAVE	SAT	4316, 4403
BRANDT	see	THOMSON
BRAUN	TV	1195, 1231
	VCR	2333
BRENDSTAR	TV	1157
BRIGHTON	TV	1052, 1231, 1233
BRIONVEGA	TV	1011, 1027, 1049, 1052, 1081, 1132, 1179, 1188, 1218, 1293, 1298
	VCR	2304, 2326, 2334, 2345, 2356, 2357
BRITANNIA	TV	1010, 1051, 1231
BROKSONIC	TV	1051
BROTHER	TV	1061, 1091
BRUNS	TV	1003, 1091, 1132, 1147, 1157, 1171, 1180, 1195, 1210, 1246, 1293, 1298, 1350
	VCR	2329, 2330
	SAT	4437, 4453, 4460
BSR	TV	1005, 1012, 1083, 1107, 1274
	VCR	1107, 2354
	COMBI	1107
BTC	TV	1210
BUSH	TV	1007, 1012, 1021, 1026, 1032, 1051, 1061, 1075, 1210, 1258, 1349
	VCR	1106, 2329, 2330, 2349, 2354
	DVD	2005, 2058
	SAT	4452, 4464
CABLETIME	SAT	4307, 4475
CADMOS	see	DESMET
CALIFORNIA	see	FORMENTI
CAMBRIDGE	SAT	4372

Brand	Type	Code
CAMPER	TV	1026, 1052, 1147, 1158
CANAIS	TV	1279
CANAL +	SAT	4390
CANAL PLUS	SAT	4390
CANALSAN.	see	SIDEC
CANDLE	see	LG
CANON	VCR	2333
CANTON	TV	1210
CAPSONIC	TV	1052, 1091
CARENA	TV	1051, 1173
CARYONSE	see	PHILIPS
CASEMA	SAT	4500
CASIO	TV	1055, 1171
	VCR	2327
CASONIO	see	OCEANIC
CATHAY	TV	1051
CCI	TV	1410
	SAT	4462
CDV	TV	1409, 1410
	DVD	2061, 2144
CELINT	TV	1021
CENTRUM	DVD	2005
CENTURION	TV	1051
CENTURY	TV	1107, 1217, 1225, 1227, 1298
CGE	TV	1007, 1012, 1039, 1051, 1052, 1080, 1081, 1141, 1145, 1157, 1190, 1217, 1239
	VCR	2310, 2326, 2327, 2356
CGM	TV	1032, 1051, 1052, 1061, 1075, 1091, 1130, 1145, 1147, 1157, 1209, 1281
	VCR	2307, 2330, 2349, 2353, 2356
CHEROKEE	SAT	4321, 4399, 4404, 4430, 4447
CIE	TV	1052, 1157, 1160, 1184, 1210, 1219
	VCR	1107, 2330, 2354
CIHAN	TV	1012, 1024, 1039, 1051
CIMLINE	TV	1157
	VCR	2330, 2354
CINEMA	TV	1061
CINEX	TV	1349
CITIZEN	VCR	2307
	SAT	4376
CITY	TV	1157
CITY COM	SAT	4314, 4352, 4369, 4376
CLARITRON.	TV	1145
CLARIVOX	TV	1012, 1052, 1120, 1125, 1171, 1184, 1217, 1233, 1298
CLATRONIC	TV	1351
	SAT	4403
CLAYTON	TV	1012, 1052, 1061, 1279
CLEMENS C.	see	HUTH
CMR	SAT	4453
COBRA	SAT	4411, 4432, 4478
COFADEL	see	THOMSON
COLOR MAT	TV	1298
COLORADO	SAT	4430, 4453
COLUMBUS	SAT	4321, 4399, 4404, 4430, 4447
COMBITECH	see	ORION
COMET	TV	1052, 1210

Brand	Type	Code
COMMEK	VCR	2310
COMMLINK	SAT	4477
COMPUTRON	TV	1014, 1052, 1075, 1157
COMSAT	SAT	4385
COMTEC	SAT	4394
CONCERTO	see	LG
CONCORDE	TV	1157
CONDOR	TV	1002, 1051, 1052, 1061, 1091, 1145, 1157, 1188, 1190, 1195, 1209, 1217, 1287
	VCR	2349, 2356, 2357
	SAT	4420
CONFORAMA	see	SONOLOR
CONIC	TV	1274
CONNEX.SAT	SAT	4386
CONRAD	TV	1061, 1130
CONTEC	TV	1047, 1091, 1157, 1209, 1210, 1231
	VCR	1107
CONTI M.	TV	1051, 1061, 1203
CONTIN. ED.	see	THOMSON
CONTINENT.	TV	1002, 1035, 1051, 1052
CORVUS	VCR	2327
COSAT	SAT	4391
COSMEL	TV	1052, 1157, 1184
COSMOS	TV	1052, 1157, 1210
CRAIG	VCR	2310, 2319
CROSLEY	TV	1024, 1051, 1136, 1217, 1239, 1287, 1298
CROWN	TV	1012, 1032, 1051, 1052, 1061, 1075, 1091, 1136, 1145, 1147, 1157, 1158, 1190, 1195, 1203, 1210, 1217, 1232, 1287, 1349
	VCR	2327, 2330, 2343, 2349, 2350, 2352
	SAT	4413, 4479
CRYSTAL	TV	1049, 1061, 1147, 1287, 1350
CS ELECTR.	TV	1210, 1225, 1231
CTC CLATRONIC	TV	1002, 1012, 1032, 1051, 1052, 1061, 1075, 1091, 1145, 1155, 1157, 1190, 1195, 1203, 1206, 1209, 1210, 1217, 1225, 1227, 1231, 1287, 1347, 1349, 1351
	VCR	2330, 2357
	DVD	2044, 2081
CURTIS	TV	1052, 1287
CXC	see	EMERSON
CYBERCOM	DVD	2060
CYBERTRON	TV	1210
CYFRA PLUS	SAT	4390
CYMATIC	TV	1012, 1231
CYV	TV	1052
D -VISION	TV	1051, 1130, 1132, 1187, 1349
DAEWOO	TV	1051, 1052, 1113, 1129, 1130, 1132, 1138, 1157, 1160, 1172, 1173, 1187, 1210, 1219, 1231, 1287

Brand	Type	Code
	VCR	1284, 2307, 2343, 2349, 2350, 2352, 2353
	DVD	2013, 2023, 2034, 2070, 2089, 2147
	SAT	4409, 4453
	COMBI	1176, 1284, 2350
	HIFI	3022
DAICHI	TV	1130, 1157
DAIGO	VCR	2310
DAIMOND	TV	1054
DAINICHI	TV	1210, 1231
	VCR	2310
DANSAI	TV	1051, 1091, 1231, 1274
	VCR	2330
DANSAT	SAT	4490
DATRONIC	see	DAEWOO
DAWA	TV	1051, 1052
DAYMATER	see	MAGNADYNE
DAYTEK	TV	1051
	DVD	2023
DAYTRON	TV	1157
	VCR	2349, 2350
DAYTRONIC	see	DAEWOO
DDC	SAT	4450
DE GRAAF	TV	1026, 1051, 1061
	VCR	2318, 2324, 2327, 2340, 2345, 2356, 2357
DECCA	TV	1049, 1051, 1052, 1062, 1065, 1172, 1206, 1231, 1287, 1349
	VCR	2326, 2327, 2345
DELFA	SAT	4397
DELTA	SAT	4350
DELTASAT	SAT	4352
DELTON	TV	1061, 1203
DEMACOLOR	TV	1051
	VCR	2356
DENKO	TV	1091
DENON	TV	1096
	DVD	2027, 2093
DENTAL	see	FORMENTI
DENVER	TV	1051, 1061, 1157
	DVD	2034, 2044, 2045
DENVOO	VCR	2310
DESAY	DVD	2088
DESMET	TV	1002, 1003, 1012, 1051, 1052, 1061, 1157, 1287, 1298
DEUTSCH	VCR	2349
DHS	see	ASTRA
DIADEM	TV	1011
DIAMOND	TV	1054, 1132, 1157, 1160
	DVD	2031
DIGICOM	SAT	4369
DIGIHOME	TV	1061
	DVD	2005
DIGILINE	TV	1051, 1189
DIGIQUEST	SAT	4303, 4304, 4369, 4370, 4397, 4504
DIGITECH	VCR	2330
DIGITOR	TV	1157
DIGITRONIC	SAT	4353, 4466, 4508
DINASTY	TV	1051, 1061, 1157, 1160
DIPRO	SAT	4356
DISISTRAT	SAT	4468
DISK EXPR.	SAT	4350

Brand	Type	Code
DISTAR	TV	1051
DISTRA	SAT	4338
DISTRATEL	SAT	4507
DISTRISAT	SAT	4468
DIVIDO	DVD	2089
DIXI	TV	1051, 1157, 1171
DMSIS	SAT	4506
DNT	SAT	4386, 4468
DOMEOS	TV	1051, 1064, 1130
DOMLAND	see	DUAL-TEC
DOMOH	TV	1051, 1052
	VCR	2307
DOMUS	TV	1051
DONATEC	SAT	4350
DORIC	TV	1021
DRACON	DVD	2060
DRAKE	SAT	4338, 4380, 4416
DTS	TV	1027, 1052, 1130, 1142, 1157
DUAL-TEC	TV	1003, 1005, 1007, 1008, 1012, 1027, 1032, 1051, 1052, 1054, 1055, 1061, 1064, 1130, 1132, 1142, 1157, 1158, 1160, 1177, 1178, 1217, 1219, 1225, 1227, 1231, 1267, 1274, 1287, 1347, 1350
	VCR	2323, 2326, 2327, 2330, 2334, 2340, 2345, 2349, 2352, 2357
	DVD	2001, 2060
DUMONT	TV	1024, 1051, 1052, 1110, 1111, 1120, 1135, 1143, 1190, 1195, 1287, 1298
	VCR	2327, 2330, 2345, 2356, 2357
DUNAI	TV	1012
DUX	TV	1052
DYNAMIC	TV	1157, 1190
DYNASAT	SAT	4376
DYNATECH	VCR	2327
DYNATRON	see	PHILIPS
ECHO	TV	1258
ECHOSTAR	TV	1051, 1157, 1231
	SAT	4305, 4315, 4329, 4371, 4375, 4379, 4386, 4390, 4392, 4398, 4399, 4430, 4451, 4453, 4455, 4471
ECO LINE	TV	1051
ECONOMIC	VCR	2310
EDAN LINE	TV	1051, 1061
	VCR	2330, 2349, 2356, 2357
EDISON	TV	1035
	VCR	2330
EEC	SAT	4462
EINHELL	SAT	4413, 4462, 4479
ELBE	TV	1011, 1012, 1027, 1037, 1046, 1051, 1080, 1081, 1130, 1186, 1188, 1231, 1233, 1262, 1272, 1349
	VCR	2307, 2327, 2342, 2349, 2352, 2357
ELBIT	TV	1051, 1267

Brand	Type	Code
ELCATECH	VCR	2330
ELCIT	see	MAGNADYNE
ELECTROT.	TV	1157
ELECTROV.	TV	1051
ELEKTA	TV	1012, 1049, 1051, 1052, 1091, 1157, 1160, 1209
	VCR	2310, 2349
ELEKTR. IND.	TV	1012
ELEKTRON.	TV	1051, 1136, 1145, 1267, 1350
ELEMIS	TV	1012, 1021, 1051, 1061, 1147, 1351
ELIN	TV	1003, 1014, 1026, 1052, 1110, 1142, 1143, 1157, 1231
	VCR	2310
	SAT	4341
ELITE	TV	1002, 1051, 1091, 1210, 1239
ELLEVISION	TV	1091, 1242
ELMAN	TV	1012, 1195, 1231
ELSAT	SAT	4395
ELSAY	VCR	2327
ELTA	TV	1039, 1052, 1091, 1157, 1217, 1231
	VCR	2327, 2330, 2349
	SAT	4401, 4420, 4468
EMANON	SAT	4409
EMATEC	see	OCEANIC
EMCO	see	IMPERIAL
EMERSON	TV	1002, 1012, 1032, 1051, 1052, 1061, 1075, 1089, 1091, 1120, 1145, 1147, 1171, 1184, 1195, 1225, 1227, 1231, 1287, 1298
	VCR	2307, 2327, 2330, 2349, 2352, 2354, 2356, 2357
EMME ESSE	SAT	4331, 4376, 4385, 4390, 4399, 4420, 4471, 4498
EMTECH	SAT	4511
ENGEL	TV	1012, 1171
	SAT	4365, 4367, 4390, 4409, 4475
ENIE	TV	1275
ENZER	TV	1258, 1303
	DVD	2023
EP SAT	see	PACE
EQUATOR	SAT	4490
EROICA	TV	1274
ERRES	see	PHILIPS
ESC	TV	1051, 1079, 1147, 1231
	VCR	2310, 2349
ESSELTE	VCR	2327, 2330
ESTEL	TV	1012
ETRON	TV	1034, 1052, 1075, 1082, 1098, 1157
ETZUKO	VCR	2330
EULANDER	see	ELBE
EUMIG	TV	1002
	VCR	2356
EURIELT	SAT	4338
EUROCOM	TV	1012
EUROLINE	TV	1052, 1232
	DVD	2091
EUROMAN	TV	1052, 1091, 1136,

Brand	Type	Code
		1147, 1231
	VCR	2345
EUROPA	SAT	4436
EUROPHON	TV	1002, 1012, 1051, 1182, 1186, 1195, 1225, 1227, 1231, 1233, 1347
EUROSAT	SAT	4401
EUROSTAR	SAT	4425
EUROSTATUS	TV	1051, 1061
EVELUX	TV	1350
EXCEL	VCR	2356
EXPERT	TV	1003, 1142
FAGOR	TV	1012, 1039
FAIR MATE	SAT	4453
FAIR VIDEO	VCR	2307
FAIRCHILD	VCR	2318
FAIRMOST	TV	1157
FAIT	SAT	4376, 4386, 4413, 4453
FALCON	TV	1157
	SAT	4430
FASTWEB	SAT	4312, 4313
FELIX	TV	1051, 1075, 1091, 1210
FENNER	TV	1051, 1052, 1061, 1132, 1136, 1157, 1160, 1173, 1209
	VCR	2330, 2349, 2352, 2376
	DVD	2009, 2038
	SAT	4378, 4409, 4420, 4430, 4453, 4460
FERGUSON	see	THORN
FIDELIS	TV	1051, 1061, 1157, 1231
FIDELITY	TV	1008, 1010, 1051, 1075, 1157, 1210, 1231, 1233, 1274
	VCR	2319, 2327, 2330, 2331
	SAT	4395
FILMNET	SAT	4390, 4463
FILSAI	TV	1157, 1231
FINLANDIA	TV	1026, 1073, 1111, 1172, 1180
	VCR	2345, 2356
FINLUX	TV	1012, 1014, 1019, 1024, 1049, 1051, 1052, 1054, 1061, 1110, 1111, 1120, 1132, 1134, 1135, 1143, 1157, 1172, 1182, 1188, 1190, 1195, 1201, 1204, 1206, 1231, 1293, 1349, 1350
	VCR	2307, 2318, 2319, 2323, 2326, 2327, 2330, 2333, 2345, 2356, 2357
	DVD	2005
	SAT	1014, 4341
FIRST LINE	TV	1002, 1003, 1007, 1008, 1011, 1012, 1032, 1037, 1039, 1049, 1051, 1052, 1061, 1062, 1079, 1132, 1155, 1157, 1160, 1172, 1186, 1188, 1203, 1217, 1231, 1233, 1267, 1287, 1347, 1349
	VCR	2307, 2318, 2320,

Brand	Type	Code
		2324, 2327, 2330, 2345, 2352, 2354
	DVD	2001, 2005, 2058, 2104
FISHER	TV	1008, 1024, 1046, 1047, 1069, 1072, 1073, 1079, 1143, 1145, 1162, 1171, 1298, 1347
	VCR	2319, 2356, 2357
FLINT	TV	1037, 1052, 1061, 1173
	VCR	2354
FLORIDA	TV	1231
FM	SAT	4391, 4401
FORGEST.	see	THORN
FORMENTI	TV	1002, 1003, 1012, 1024, 1026, 1039, 1049, 1051, 1052, 1054, 1061, 1091, 1120, 1142, 1145, 1157, 1160, 1175, 1177, 1186, 1188, 1190, 1192, 1231, 1239, 1287
	VCR	2307, 2330, 2345, 2349, 2354, 2357
	DVD	2005
FORTEC STAR	SAT	4370
FORTRESS	TV	1298
FRABA	TV	1051, 1147, 1267
FRACARRO	SAT	4336, 4339, 4376, 4409, 4411, 4414, 4430, 4432, 4466, 4471, 4480, 4494
FRANCE TEL.	SAT	4463, 4500
FREECOM	SAT	4409
FREEONE	SAT	4405
FRESAT	SAT	4409
FREEWAVE	SAT	4511
FRONTECH	TV	1012, 1026, 1091, 1157, 1217, 1225, 1231, 1274
	VCR	2330
FS SOUND	TV	1157, 1206
FST	see	DECCA
FTE MAXIMAL	SAT	4331, 4342, 4361, 4376, 4378, 4391, 4401, 4403, 4406, 4453, 4480
FUBA	SAT	4321, 4338, 4350, 4367, 4385, 4386, 4399, 4409, 4420, 4435, 4444
FUJI	TV	1209
FUJITECH	TV	1052
FUJITSU GENERAL	TV	1005, 1027, 1051, 1052, 1061, 1110, 1142, 1192, 1195, 1210, 1231, 1274
	VCR	2327
FUMEO	TV	1005
FUNAI	TV	1012, 1046, 1091, 1107, 1157, 1177
	VCR	2327, 2330, 2331
	DVD	2056
	COMBI	1107, 2327, 2331
FURICHI	TV	1303
FUTRONIC	TV	1091
FUTURET.	see	EMERSON
G - SAT	SAT	4490
GALA	TV	1274
GALACTEX	TV	1091, 1231

Brand	Type	Code
GALAXY	TV	1026, 1051, 1052, 1055, 1120, 1145, 1147, 1190, 1195, 1217, 1231
	VCR	2327
	SAT	4390, 4391, 4397, 4401, 4438, 4442, 4453, 4477
GALERIA	TV	1157
GBC	TV	1012, 1024, 1034, 1047, 1052, 1075, 1157, 1160, 1172, 1209, 1210, 1219, 1225
	VCR	2330, 2349
GE	TV	1180, 1215
	VCR	2326
GEANT CAS.	see	OCEANIC
GEBER	TV	1003
GEC	TV	1003, 1015, 1021, 1026, 1039, 1047, 1051, 1052, 1172, 1192, 1231
	VCR	2330, 2345
GELOSO	TV	1012, 1024, 1034, 1157, 1160, 1210, 1219
	VCR	2330, 2349
GEMSOUND	TV	1157, 1210
GENERAL	TV	1047, 1157
	VCR	2327, 2329, 2330, 2342, 2352, 2354
GENERAL CORPORAT.	TV	1005, 1034, 1046, 1061, 1142, 1192, 1231
	VCR	2310
GENERAL ELECTRIC	TV	1288
GENERAL STAR	TV	1091, 1157, 1160
GENERAL TECHNIC	VCR	2327, 2330
GENEXXA	TV	1210
GIANT	TV	1049, 1133, 1157, 1231, 1258
GITEM	TV	1049, 1052, 1144, 1180, 1198
GM - GMC	TV	1051, 1052, 1091, 1157, 1190
GMI	SAT	4413
GOLD	DVD	2064
GOLDBOX	SAT	4390
GOLDEN INT.	SAT	4317
GOLDFUNK	TV	1032, 1061
GOLDHAND	TV	1157, 1231
	VCR	2329, 2330
GOLDI	TV	1206
GOLDLINE	TV	1037, 1210
GOLDMEDAL	VCR	2327, 2330
GOLDSTAR	see	LG
GOLDTECH	TV	1032, 1051, 1061
	VCR	2330
GOLDVISION	see	SONOKO
GOODING	TV	1035
GOODMANS	TV	1012, 1032, 1046, 1051, 1052, 1061, 1075, 1089, 1113, 1130, 1132, 1145, 1157, 1158, 1160, 1180, 1187, 1203, 1204, 1210, 1215, 1231, 1287, 1349, 1350

Brand	Type	Code
	VCR	2310, 2323, 2324, 2327, 2330, 2331, 2340, 2349, 2350
	DVD	2001, 2005, 2058
	COMBI	1176, 1284
GORENJE	TV	1051, 1052, 1136, 1145, 1350
GP	TV	1231
GPM	TV	1091, 1157, 1210, 1274
GR 15	VCR	2330
GRAETZ	see	ITT/NOKIA
GRANADA	TV	1015, 1019, 1021, 1026, 1034, 1046, 1047, 1049, 1051, 1052, 1069, 1070, 1071, 1072, 1077, 1079, 1086, 1088, 1093, 1096, 1111, 1125, 1132, 1133, 1134, 1142, 1147, 1157, 1164, 1172, 1180, 1211, 1214, 1215, 1231, 1232, 1246, 1262, 1279, 1365
	VCR	2304, 2307, 2314, 2323, 2324, 2326, 2327, 2330, 2333, 2340, 2345, 2346, 2350, 2356
	SAT	4355, 4358, 4464
GRANDEN	see	FORMENTI
GRANDIN	TV	1002, 1003, 1012, 1021, 1032, 1037, 1051, 1052, 1061, 1130, 1132, 1157, 1158, 1168, 1173, 1203, 1206, 1209, 1210, 1232, 1354
	VCR	2307, 2330, 2349, 2350, 2354
	DVD	2005, 2058
	SAT	4338, 4367
	COMBI	1106
GREAT WALL	TV	1051, 1091, 1184
GRENADIER	TV	1012, 1052, 1157, 1288
	VCR	2349
GRONIC	TV	1012, 1051, 1052, 1157, 1171, 1186, 1231
	VCR	2330
GROTHUSEN	SAT	4409
GRUNDIG	TV	1003, 1034, 1035, 1089, 1125, 1132, 1133, 1137, 1141, 1144, 1148, 1152, 1154, 1188, 1220, 1239, 1350
	VCR	2323, 2333, 2343, 2344, 2362
	DVD	2003, 2004, 2089
	SAT	4372, 4390, 4435, 4461, 4464, 4493
	COMBI	1137, 1144, 1153, 1154, 1220, 1353
	HIFI	3034
GTRONIC	TV	1051
GTT	TV	1051, 1061, 1157, 1190, 1209
	VCR	2357
H & B	TV	1061

Brand	Type	Code
	DVD	2044, 2059
HAIER	TV	1130
	DVD	2072
HALIFAX	TV	1091
HAMERSTEIN	TV	1082, 1091, 1098, 1157, 1161, 1231
HAMLET	DVD	2009
HAMPTON	TV	1024, 1231
HANIMEC	TV	1210
HANSEATIC	TV	1002, 1003, 1006, 1008, 1012, 1024, 1039, 1047, 1049, 1051, 1052, 1054, 1061, 1064, 1072, 1083, 1107, 1130, 1132, 1141, 1147, 1157, 1175, 1187, 1188, 1209, 1210, 1231, 1245, 1267, 1275
	VCR	1107, 2307, 2323, 2330, 2342, 2345, 2354, 2362
	SAT	4395, 4408
HANTAREX	TV	1008, 1052, 1157, 1186
	VCR	2307
HANTOR	SAT	4409
HANURI	see	LA SAT
HARMAN KARDOM	VCR	2320, 2342
HARROW	TV	1061
HART. UND HELLING	SAT	4462
HARWOOD	see	CROWN
HCM	TV	1012, 1051, 1052, 1091, 1157, 1168, 1209, 1347
	VCR	2330
HEIRU	TV	1091
	SAT	4435
HELECTR.	see	FORMENTI
HELIOCOM	SAT	4331
HEMMERM.	TV	1008, 1182, 1195, 1231, 1347
HEXA	TV	1012
HIFIVOX	see	THOMSON
HIGASHI	TV	1231
HIGHIWA	see	KAISUI
HIKONA	see	KAISUI
HILINE	TV	1051, 1075, 1091, 1157
	VCR	2307
HINARI	TV	1034, 1047, 1051, 1052, 1065, 1089, 1091, 1157, 1171, 1210, 1274
	VCR	2330
	SAT	1091, 4490
HIRSCHM.	SAT	4376, 4385, 4420, 4422, 4435, 4462
HISAWA	TV	1037, 1210
	VCR	2354
	SAT	4403
HISENSE	TV	1026, 1079, 1132, 1303
HISHITO	see	TOSHIBA
HISONIC	TV	1075, 1157, 1162
HIT	TV	1298
HITACHI	TV	1006, 1014, 1015, 1019, 1021, 1026, 1046, 1047, 1051, 1061, 1068, 1071,

Brand	Type	Code
		1086, 1092, 1096, 1099, 1100, 1101, 1130, 1132, 1134, 1135, 1169, 1183, 1187, 1194, 1202, 1204, 1206, 1231, 1253, 1274, 1289, 1344
	VCR	2318, 2319, 2323, 2326, 2327, 2340
	DVD	2005, 2066, 2113
	SAT	4341, 4464
	COMBI	1262
HITEKER	DVD	2067
HITSU	TV	1037, 1210
HMV	VCR	2326
HOHER	TV	1061, 1203, 2058, 4367
	DVD	2005, 2058
	SAT	4367
HORIZONT	see	PHILIPS
HORNYPHON	TV	1051, 1052
HOSHAI	TV	1032, 1061, 1209, 1210
HOSPITAL.	TV	1061
HOUSTON	SAT	4430
HOWELL	TV	1032, 1061
HUMAX	SAT	4369, 4370, 4397
HUTH	SAT	4385, 4413, 4460, 4475, 4477, 4479
HYPER	TV	1012, 1039, 1051, 1052, 1075, 1091, 1147, 1157, 1159, 1209, 1210, 1225, 1231, 1274
	VCR	2330, 2349
HYPSON	TV	1051, 1052, 1061, 1091, 1157, 1206, 1233
	VCR	2330, 2354
	SAT	4338
HYUNDAI	TV	1052
	DVD	2033, 2035, 2036
	SAT	4352, 4469, 4506
I - CAN	SAT	4305
I. V.	TV	1052
IBERIA	TV	1081
IBERVISAO	TV	1003, 1008, 1012
ICE	TV	1049, 1051, 1052, 1075, 1091, 1157, 1210, 1217, 1231
ICS	TV	1091, 1157, 1210, 1231
ICX INTERNAT.	SAT	4487
ID DIGITAL	SAT	4369
IEG	TV	1052, 1231
IMC	TV	1053
IMEX	SAT	4338, 4411
IMPER	TV	1052, 1091, 1157, 1210
IMPERIAL	TV	1007, 1012, 1039, 1051, 1052, 1080, 1081, 1091, 1145, 1157, 1188, 1190, 1206, 1217, 1219, 1225, 1227, 1239, 1262, 1287
	VCR	2310, 2327, 2356
	SAT	4452
INCOBE	TV	1072, 1157, 1347
INDESIT	TV	1197
INDIANA	TV	1012, 1052
INGELEN	TV	1003, 1037, 1204

Brand	Type	Code
INGERSOLL	TV	1003, 1157
	VCR	2310
INNO HIT	TV	1024, 1051, 1052, 1054, 1061, 1075, 1091, 1119, 1130, 1132, 1145, 1157, 1172, 1209, 1210, 1225, 1227, 1231
	VCR	2310, 2330, 2345, 2349, 2354
	DVD	2005
INTERBURG	TV	1091, 1157
INTERBUY	TV	1075, 1091, 1103, 1157, 1210, 1225
	VCR	2307, 2330
INTERDISC.	TV	1052, 1180, 1198, 1289, 1352
INTERFUNK	TV	1003, 1010, 1017, 1021, 1026, 1049, 1052, 1054, 1072, 1132, 1145, 1190, 1198, 1215, 1217, 1240, 1265, 1279, 1295, 1298
	VCR	2345
INTERNAT.	VCR	2350
	SAT	4425, 4453
INTERSAT	see	JOHANSSON
INTERVIDEO	VCR	2307, 2327
INTERVISION	TV	1003, 1012, 1039, 1049, 1051, 1052, 1091, 1103, 1141, 1145, 1147, 1157, 1173, 1175, 1195, 1210, 1219, 1225, 1227, 1231
	VCR	2327, 2329, 2330, 2342, 2349
	SAT	4401
INTRON	TV	1091
INWAH	TV	1130
IRRADIO	TV	1012, 1032, 1051, 1052, 1061, 1075, 1091, 1119, 1120, 1123, 1157, 1175, 1210, 1225, 1258, 1274
	VCR	2307, 2323, 2330, 2345, 2356, 2357, 2376
	DVD	2001, 2002, 2005, 2024, 2057, 2059, 2109
	SAT	4430
	COMBI	1157, 1185, 1258, 1262, 1381
ISKRA	TV	1012, 1145, 1147, 1195, 1231
ISUKAI	TV	1210
ISV	see	JOHANSSON
ITALTEL	SAT	4471
ITC	TV	1012, 1051, 1231
	SAT	4453
ITL	TV	1157
ITS	TV	1051, 1052, 1075, 1091, 1157, 1210, 1217, 1231
	SAT	4403
ITT	TV	1003, 1006, 1008, 1010, 1013, 1017, 1019, 1021, 1024, 1026, 1034, 1046, 1051, 1052, 1072, 1079, 1089, 1091,

Brand	Type	Code
		1098, 1111, 1120, 1142, 1143, 1149, 1157, 1164, 1190, 1192, 1215, 1358
	VCR	2302, 2310, 2326, 2330, 2340, 2356, 2357, 2379
	SAT	4302, 4355, 4374, 4390, 4443
ITV	TV	1052, 1091, 1160, 1219
	VCR	2307, 2349
IV	TV	1052
JASON	VCR	2307
JCE	TV	1210
JEC	see	TOSHIBA
JEEMON	SAT	4401
JEEPSSEN	SAT	4511
JENSEN	VCR	2326
JERROLD	SAT	4487
JET POINT	TV	1052, 1098
JINLIPU	TV	1157
JINN SONIC	VCR	2349
JNL	TV	1258
JOCEL	TV	1039, 1051, 1201
JOHANSSON	SAT	4403
JOHNSON	TV	1231
JOK	SAT	4430
JPS	TV	1103
JRC	TV	1039
JSR	SAT	4391, 4401
JVC	TV	1026, 1046, 1047, 1075, 1114, 1115, 1129, 1293, 1298, 1315
	VCR	1129, 2316, 2326, 2334, 2374
	DVD	2022
	SAT	4493
	HIFI	3029, 3030
KABEL	TV	1083
KAIDO	TV	1026
KAISER	TV	1052, 1209
KAISUI	TV	1037, 1051, 1061, 1075, 1130, 1140, 1157, 1173, 1201, 1209, 1210, 1231
	VCR	2330
KAMAR	TV	1162
KAMBROOK	TV	1012, 1052, 1091, 1175, 1231, 1289
	VCR	2327
KAMOSONIC	TV	1347
KAMP	see	FORMENTI
KANARY	SAT	4378
KANGSLEY	see	FORMENTI
KANSAI	TV	1051
	VCR	2327, 2329, 2330
KAON MEDIA	SAT	4303
KAOSHO	see	SAMSUNG
KAPSCH	see	ITT/NOKIA
KARCHER	TV	1037, 1039, 1051, 1052, 1130, 1136, 1157, 1186, 1206, 1209, 1231, 1233, 1347, 1349
	VCR	2310, 2345
KARDOM	VCR	2314, 2342
KATHREIN	SAT	4361, 4376, 4394, 4410, 4435, 4463
KAWA	TV	1075, 1210
KAWASHO	see	FORMENTI
KAYA	TV	1091, 1157

Brand	Type	Code
KELVINATOR	TV	1017
KENDO	TV	1011, 1012, 1027, 1034, 1037, 1052, 1061, 1083, 1157, 1175, 1188, 1195, 1225, 1227, 1231
	VCR	2302, 2304, 2310, 2314, 2319, 2354
KENNEDY	TV	1005, 1011, 1024, 1027, 1080, 1142, 1149, 1188, 1192, 1225, 1262
	VCR	2304, 2334
KENNEX	TV	1032, 1051, 1061, 1130, 1158, 1177, 1203
	VCR	2349, 2350
	DVD	2005, 2024
	SAT	4466
KENWOOD	VCR	2326, 2342, 2356, 2357
	DVD	2027, 2115
	SAT	4390
	HIFI	3031, 3032
KERION	TV	1051, 1052
KEYMAT	DVD	2009
KIC	TV	1162, 1231, 1233
KIMAY	TV	1091
KINGDHOME	TV	1061
KIOTA	TV	1075, 1082, 1091, 1157, 1173
KISS	DVD	2023
KITON	TV	1032, 1052, 1061, 1177
KITT	TV	1052, 1091, 1231
KIYOGIN	TV	1052
KIZUKI	SAT	4478
KLARMAX	TV	1012, 1186, 1231, 1233, 1279
K-MART	VCR	2307
KNEISSEL	TV	1032, 1037, 1051, 1052, 1061, 1080, 1130, 1160, 1171, 1188, 1206, 1233, 1272
	VCR	2307, 2354
	COMBI	1042
KOBALTR.	see	NEWMAR
KOBIC	TV	1157
KODA	DVD	2044
KOLSTER	TV	1012, 1052, 1091, 1186, 1195, 1210, 1219, 1225, 1227, 1231, 1233
	VCR	2354
KONG WAM	see	KAISUI
KONICHI	TV	1157
KÖNIG	TV	1002, 1024, 1051
KONKA	TV	1075, 1132, 1206, 1210, 1267
KONTAKT	TV	1035
KORPEL	TV	1051
KÖRTING	TV	1002, 1051, 1136, 1145, 1298
	VCR	2345
KOSMOS	SAT	4361
KOTRON	TV	1012, 1091, 1157
KR	SAT	4378
KRAKING	TV	1012
KRIESEL.	SAT	4435, 4450
KRIESLER	see	PHILIPS
KRONNE	TV	1012, 1231
	VCR	2342

Brand	Type	Code
KTV	VCR	2307
KUBA ELECTRONIC	TV	1008, 1012, 1026, 1231
	VCR	2307, 2310, 2319, 2326, 2327, 2333, 2343, 2356, 2357, 2362
KUKKAI	TV	1032
	SAT	4374
	COMBI	1140
KUNYA	VCR	2316
KURO	see	SANYO
KYOSTAR	SAT	4339, 4409, 4508
KYOTO	TV	1012, 1231
LA SAT	SAT	4400, 4420
LAEM SAT	SAT	4391, 4401
LANDPORT	VCR	2307
LAVIS	TV	1003, 1143, 1171, 1233
	VCR	2330
LAZER	TV	1051, 1123
LCE	TV	1075
LEADER	TV	1157
LECSON	TV	1350
LEGEND	TV	1052, 1091, 1157, 1184, 1231
LEMON	SAT	4320
LENCO	TV	1003, 1008, 1039, 1051, 1052, 1061, 1091, 1143, 1146, 1147, 1157, 1160, 1195, 1274
	VCR	2330, 2349
	DVD	2034
	SAT	4409
	COMBI	1157
LENNOX	SAT	4420
LENOIR	TV	1008, 1032, 1051, 1052, 1061, 1091, 1157, 1158, 1160, 1209, 1231, 1343, 1394, 1395, 1396, 1397, 1398, 1399, 1400, 1401
	VCR	2307, 2330, 2349, 2356
	DVD	2046, 2047, 2049
LEXUS	TV	1051, 1052, 1091, 1190
LEYCO	TV	1051, 1091, 1107, 1157, 1172, 1209, 1274, 1275
	VCR	2330
LG	TV	1005, 1012, 1026, 1049, 1051, 1052, 1082, 1091, 1098, 1119, 1132, 1141, 1142, 1157, 1158, 1175, 1183, 1203, 1206, 1217, 1219, 1225, 1231, 1258, 1274, 1275, 1288, 1347, 1355
	VCR	2307, 2327, 2342
	DVD	2024, 2072, 2101
	COMBI	1042, 1288
LIESENKÖT.	TV	1049, 1052, 1240
LIFE	TV	1157
LIFETEC	TV	1032, 1049, 1051,

Brand	Type	Code
		1052, 1061, 1091, 1130, 1155, 1157, 1158, 1160, 1203, 1210, 1274
	DVD	2060
LIGHTSTAR	see	KAISUI
LION	SAT	4462
LLOYD'S	TV	1021, 1082, 1091, 1120, 1125, 1157, 1161, 1231
	VCR	2327
LME	see	PATHE CINEMA
LOEWE	TV	1052, 1053, 1054, 1062, 1143, 1194, 1205, 1231, 1266, 1289, 1298
	VCR	2307, 2318, 2345
	DVD	2004, 2037
LOGIK	TV	1032, 1051, 1052, 1061, 1065, 1157, 1190
	VCR	2310, 2330
LOGISTIC	TV	1173
LOVE	see	ELBE
LTV	see	OCEANIC
LUMA	TV	1005, 1027, 1034, 1052, 1061, 1130, 1132, 1142, 1157, 1160, 1188, 1192, 1231
LUMATRON	TV	1011, 1027, 1051, 1061
LUPUS	see	ANKARO
LUXMAN	DVD	2066
LUXMAY	TV	1184
LUXON	VCR	2327, 2330
LUXOR	TV	1003, 1006, 1010, 1013, 1014, 1019, 1021, 1026, 1051, 1079, 1111, 1119, 1132, 1134, 1135, 1183, 1201, 1204, 1206, 1347, 1350
	VCR	2302, 2314, 2345, 2356, 2357
	SAT	1014, 4340, 4341, 4355, 4443, 4498, 4499
LYONNASE CABLE	SAT	4500
LYOTRON	see	LG
M.D.C	TV	1051
M.ELECTR.	TV	1008, 1019, 1051, 1052, 1053, 1110, 1111, 1120, 1130, 1134, 1135, 1141, 1143, 1157, 1160, 1188, 1204, 1219, 1232, 1355
	VCR	2327
	SAT	1014, 1134, 4340
M.NET	SAT	4350
MACAB	SAT	4390, 4406, 4500
MACRON	VCR	2310
MAESTRO	SAT	4321, 4399, 4404, 4430, 4447
MAGAVOX	see	PHILIPS
MAGIKE	SAT	4351
MAGNADYNE	TV	1008, 1012, 1024, 1051, 1052, 1145, 1157, 1190, 1195, 1219, 1298
	VCR	2307, 2326, 2356
MAGNAFON	TV	1012, 1051, 1052,

Brand	Type	Code
		1120, 1186, 1195, 1231
MAGNASON.	TV	1052
	VCR	2319, 2326, 2356
MAGNAVOX	TV	1049, 1132
MAGNEX	TV	1052, 1091
	DVD	2034
MAGNUM	TV	1051, 1157, 1190, 1212, 1351
MAJESTIC	DVD	2057
MANDOR	TV	1091
MANESTH	TV	1002, 1003, 1012, 1021, 1051, 1052, 1083, 1091, 1093, 1231
	VCR	2327, 2330, 2352, 2354
MANHATTAN	TV	1007, 1032, 1052, 1061, 1157
	DVD	2009, 2089
	SAT	4303, 4370, 4385, 4387, 4393, 4401, 4411, 4414, 4486
MARANTZ	TV	1049, 1052
	VCR	2307, 2323, 2324, 2340, 2345, 2354
	DVD	2037
	SAT	4468
MARECH	TV	1002, 1052
	VCR	2329, 2330
MARK	TV	1147, 1160
MARQUANT	VCR	2329, 2330
MARSHALL	TV	1157, 1210
MARTA	VCR	2307
MASCOM	TV	1051, 1204, 1349
	SAT	4411
MASCOT	TV	1217
MASPRO	SAT	4394, 4410, 4453
MASTERS	TV	1287
MATAV	SAT	4361
MATCH ITALIA	TV	1052, 1091, 1157
	VCR	2350
MATSUI	TV	1008, 1012, 1026, 1035, 1039, 1046, 1051, 1052, 1065, 1075, 1079, 1083, 1091, 1093, 1104, 1133, 1141, 1147, 1155, 1157, 1170, 1206, 1219, 1231, 1350
	VCR	2307, 2349, 2350, 2354
	DVD	2067
	SAT	4493
	COMBI	1106, 1258, 2020
MATSUKA	TV	1091, 1231
MAXAM	TV	1091, 1157
	VCR	2330
MAXDORF	TV	1091, 1258
MAXELL	TV	1061, 1157, 1209, 1274
	VCR	2330
MAXIMAL	TV	1034
	VCR	2357
MAXON	TV	1157
MAXWELL	TV	1051, 1195
MB LINE	TV	1091
MC MICHAEL	see	PHILIPS
MCE	TV	1091, 1157, 1242
MCM	TV	1157
MECOA	TV	1051
MECOTEX	DVD	2059



Brand	Type	Code
		1012, 1026, 1027, 1034, 1049, 1051, 1052, 1053, 1054, 1055, 1062, 1077, 1083, 1088, 1107, 1129, 1130, 1132, 1136, 1141, 1144, 1145, 1148, 1157, 1178, 1188, 1189, 1190, 1206, 1217, 1219, 1232, 1235, 1238, 1240, 1245, 1265, 1287, 1298, 1337, 1347, 1352
	VCR	2310, 2318, 2326, 2340, 2345, 2349, 2354, 2356, 2357
	COMBI	1107
NECOLA	VCR	2307
NEHAUSAT	SAT	4453
NEI	TV	1012, 1051, 1052, 1061, 1184, 1210, 1262, 1287
	VCR	2345
NEOTION	SAT	4329
NESCO	TV	1003, 1011, 1089, 1172, 1178, 1225
	VCR	2327, 2330, 2354
NETWORK	SAT	4490
NEU	TV	1130
NEUFUNK	TV	1061, 1287
	DVD	2005, 2058
	SAT	4367
NEUSAT	SAT	4453
NEVELING	SAT	4394, 4450
NEW WAVE	SAT	4476
NEW GOLD.	see	SONOKO
NEWMAR	TV	1012, 1052, 1186, 1231, 1347
NEWORLD	see	KAISUI
NEWTECH	TV	1051, 1157, 1231
NEWTRON	DVD	2059, 2082
NEWVISION	TV	1123
NEX	TV	1298
NEXIUS	TV	1206, 1337
	DVD	2005
NEXT WAVE	SAT	4351, 4476
NICAMAGIC	see	FORMENTI
NIKE	TV	1051
NIKKEI	TV	1032, 1052, 1061, 1091, 1158, 1183, 1231, 1274
	VCR	2307
NIKKO	TV	1052, 1184
NINBUS	SAT	4391
NISSAN	TV	1098
NOBLEX	TV	1046, 1047, 1075, 1157, 1160, 1161
NOBLIKO	TV	1120, 1195, 1225, 1227, 1231
NOGAMATIC	see	THOMSON
NOKIA	TV	1003, 1013, 1014, 1019, 1051, 1052, 1053, 1061, 1079, 1091, 1110, 1111, 1132, 1134, 1135, 1143, 1201, 1204, 1337, 1350, 1423
	VCR	2304, 2326, 2350, 2356, 2357, 2379
	DVD	2005, 2034
	SAT	4332, 4340, 4341, 4374, 4382, 4390,

Brand	Type	Code
		4443, 4453, 4462, 4464, 4498, 4499
	COMBI	1358
NORDING	TV	1195
NORDLAND	TV	1012
NORDMENDE	TV	1017, 1021, 1024, 1036, 1180, 1194, 1198, 1200, 1202, 1215, 1277
	VCR	2316, 2322, 2326, 2334, 2348
	DVD	2060, 2098
	SAT	4409, 4418, 4450, 4452
	HIFI	1202
NORDTON	see	SELECO
NORDWAY	TV	1007, 1145
NORFOLK	TV	1020
NORKABEL	SAT	4487
NORM N	TV	1052
NORMEREL	TV	1630
NORTEK	TV	1032, 1052, 1061, 1158
	DVD	2073
NORTON	TV	1157, 1209
NOVA	TV	1143, 1274
NOVATRONIC	TV	1051, 1052, 1091, 1130, 1143, 1157, 1160, 1287
NOVIS	SAT	4403
NTC	SAT	4477
NUCLEAR	see	PRANDONI
NUMERI	SAT	4390
CABLE		
NU-TEC	TV	1079, 1258
	DVD	2001
NYKOS	DVD	2098
O GENERAL	TV	1046, 1157
OCEANIC	TV	1003, 1006, 1013, 1014, 1017, 1019, 1021, 1026, 1079, 1132, 1134, 1135, 1177, 1198, 1215
	VCR	2302, 2323, 2324, 2326, 2340, 2356, 2357, 2379
	SAT	4341, 4355, 4390, 4498, 4499
OCTAGON	SAT	4409
OCTAL	TV	1231
	SAT	4316
OCTAN	see	PHILIPS
ODEON	see	AGASHI
OEC ELECTR	TV	1274
OFFEL	SAT	4393
OKANO	TV	1049, 1052, 1145, 1157
	VCR	2302, 2330, 2354
	SAT	4361, 4413
OLIDATA	TV	1378
	DVD	2067
OLMAL	see	ALBIRAL
OLYMPIC	TV	1157, 1209
	SAT	4420, 4477
OLYMPUS	VCR	2333
	SAT	4453
OMEGA	TV	1075, 1091, 1210
	VCR	2327
ONCEAS	TV	1157, 1219, 1231
ONDIAL	SAT	4508
ONDIOLA	TV	1002, 1051
ONIDA	TV	1049

Brand	Type	Code
ONIEL	TV	1157
ONKYO	VCR	2354
	DVD	2120
ONWA	TV	1032, 1075, 1091, 1138, 1140, 1190, 1201, 1210
OPENTEL	SAT	4314
OPTEX	SAT	4317, 4319, 4321, 4322, 4323, 4324, 4338, 4401, 4403, 4453
OPTONICA	VCR	2324
ORAVA	TV	1012, 1051, 1052, 1287, 1298
	SAT	4463, 4468
ORBISAT	TV	1231
ORBIT	TV	1051, 1145
	SAT	4481
ORBITECH	SAT	4372, 4408, 4409, 4440
ORBITER	TV	1145
ORDA	SAT	4323
ORIENT	TV	1157
ORION	TV	1004, 1008, 1020, 1051, 1052, 1055, 1056, 1061, 1065, 1075, 1083, 1087, 1091, 1102, 1104, 1105, 1106, 1107, 1132, 1157, 1158, 1182, 1189, 1203, 1206, 1210, 1274, 1287, 1337, 1422, 1425
	VCR	1107, 2354, 2377
	DVD	2023, 2041, 2103
	SAT	1087
	COMBI	1004, 1102, 1106, 1107
ORION (HUNGARY)	TV	1012, 1020, 1049, 1051, 1052, 1059, 1075, 1104, 1289
ORITRON	DVD	2057
ORLINE	see	KONKA
ORMOND	TV	1032, 1052, 1061
ORSON	VCR	2327
OSAKA	see	SHORAI
OSAKI	TV	1052, 1061, 1091, 1107, 1210, 1231
	VCR	2307, 2327, 2330
OSCAR	TV	1051, 1079
	VCR	2356
OSIO	TV	1119, 1210
	VCR	2307
OSO	TV	1210
OSUME	see	HITACHI
OTAKE	TV	1083, 1107
	COMBI	1107
OTF	TV	1012, 1049, 1051
OTHER LINE	TV	1002, 1012, 1024, 1026, 1039, 1047, 1049, 1051, 1052, 1054, 1062, 1083, 1144, 1147, 1154, 1231, 1235
OTTO VERSAND	TV	1002, 1003, 1006, 1007, 1008, 1012, 1014, 1015, 1024, 1026, 1039, 1047, 1049, 1051, 1052, 1053, 1054, 1055, 1062, 1064, 1068, 1070, 1072, 1075, 1077, 1083, 1087,

Brand	Type	Code
		1107, 1130, 1132, 1141, 1144, 1146, 1147, 1154, 1157, 1164, 1165, 1175, 1180, 1182, 1189, 1194, 1209, 1211, 1216, 1221, 1224, 1225, 1231, 1232, 1235, 1238, 1245, 1246, 1267, 1272, 1287, 1352, 1365, 1374, 1646
	VCR	2323, 2349
	SAT	4408, 4435
	COMBI	1107
OVP	TV	1051, 1052
OXFORD	SAT	4430
PACE	SAT	4347, 4358, 4390, 4414, 4424, 4441, 4464, 4490
PACIFIC	DVD	2060
	SAT	4406
PAEL	TV	1120, 1125, 1231
PALCOM	SAT	4350, 4399
PALLADIUM	TV	1051, 1054, 1130, 1145, 1157, 1188, 1217, 1232, 1337
	VCR	1107, 2304, 2307, 2310, 2314, 2318, 2319, 2326, 2327, 2330, 2340, 2342, 2345, 2354, 2356, 2357
PALSAT	SAT	4372, 4440
PALSONIK	TV	1049, 1052, 1091, 1157, 1210, 1231, 1274
	VCR	2327, 2354
PANAMA	TV	1051, 1052, 1091, 1217, 1231
PANASAT	SAT	4461
PANASHIBA	TV	1157
PANASONIC	TV	1012, 1021, 1096, 1144, 1146, 1154, 1163, 1164, 1167, 1211
	VCR	2307, 2333, 2346, 2347
	DVD	2027, 2119
	SAT	4424, 4441
	COMBI	1164
	HIFI	3015
PANAVISION	TV	1051, 1091, 1103, 1155
PANAVOX	TV	1157
PANDA	TV	1211
PANORAMA	TV	1103, 1155, 1210
	VCR	2307, 2349
PANORAMIC	TV	1198
PATHÉ CINEMA	TV	1002, 1012, 1039, 1145, 1231, 1233
PATHÉ MAR.	see	THOMSON
PATRIOT	SAT	4508
PAUSA	TV	1012, 1157
PCM	TV	1002, 1051, 1052
	VCR	2307
PENTAX	VCR	2318
PEONY	TV	1133, 1242
PERDIO	VCR	2327
PERFEKT	TV	1051
PERSHIN	TV	1125
PHANTOM	SAT	4430
	see	DESMET

Brand	Type	Code
PHILARMON.	TV	1219, 1231
PHILBIX	see	DESMET
PHILCO	TV	1007, 1012, 1024, 1039, 1046, 1051, 1052, 1080, 1081, 1136, 1141, 1145, 1157, 1171, 1190, 1217, 1219, 1239, 1287, 1298
	VCR	2310, 2326, 2327, 2330, 2342, 2356
PHILIPS	TV	1008, 1025, 1027, 1046, 1049, 1051, 1052, 1053, 1054, 1057, 1130, 1132, 1142, 1144, 1155, 1160, 1172, 1194, 1206, 1231, 1232, 1233, 1238, 1262, 1279, 1287, 1289, 1293, 1298, 1364, 1365, 1366, 1374, 1383
	VCR	2310, 2323, 2324, 2327, 2333, 2340, 2345
	DVD	2004, 2037, 2054, 2056, 2136
	SAT	4309, 4390, 4422, 4463, 4464, 4490, 4493
	COMBI	1132, 1220, 1262, 2323
	HIFI	3034, 3045
PHOENIX	TV	1002, 1024, 1049, 1051, 1052, 1061, 1186, 1287
	VCR	2307, 2349, 2356
	DVD	2005
	SAT	4413, 4490
PHONOLA	see	PHILIPS
PHONOTR.	DVD	2034, 2044
	SAT	4385, 4401, 4477
PIONEER	TV	1003, 1049, 1061, 1075, 1078, 1194, 1206, 1222, 1289, 1349
	VCR	2318, 2323, 2326, 2340, 2345
	DVD	2068
	SAT	4343, 4390
	HIFI	3051, 3052, 3053, 3082
PK SAT	see	HIRSCHMANN
PLANTRON	TV	1051, 1052, 1091, 1157
PLAYDOR	TV	1091
PLAYSONIC	TV	1233, 1298, 1347
	VCR	2356
PMB	SAT	4328, 4330, 4366, 4405
POLSAT	SAT	4316
POLYTRON	see	KATHREIN
POPPY	TV	1157
PORTLAND	TV	1051, 1056, 1130, 1160
	VCR	2307, 2343, 2349, 2350, 2353
POWER SKY	SAT	4353, 4370
POWERPOINT	TV	1035
PRANDONI	TV	1020, 1024, 1026, 1034, 1049, 1120,

Brand	Type	Code
		1157, 1195, 1206, 1225, 1227
PRECISION	TV	1231, 1274
PREDKI	SAT	4403, 4414
PREMIER	TV	1091
	SAT	4477, 4499
PRIMA	TV	1061, 1091, 1103, 1157, 1231, 1274
PRIME	TV	1061
PRIMUS	TV	1132
PRINCE	see	PRANDONI
PRINCESS	TV	1157, 1274
PRINZ	TV	1107, 1183
	VCR	1107, 2327
PROCYON	see	PHILIPS
PROFESSOR	TV	1049
PROFEX	TV	1003, 1007, 1012, 1026, 1039, 1157
	VCR	2329, 2330, 2340
PROFILINE	TV	1061
PROFILO	TV	1039, 1051, 1052, 1165, 1180, 1206, 1349, 1351
PROFITRON.	TV	1052, 1195
PROLINE	TV	1012, 1061, 1087, 1172, 1187, 1206, 1287
	VCR	2327, 2330, 2345, 2348
	DVD	2057, 2067
PROMAX	see	PACE
PROSAT	SAT	4450, 4452, 4477
PROSCO	VCR	2307, 2327, 2350
PROSIO	VCR	2307
PROSONIC	TV	1049, 1051, 1075, 1232
PROTECH	TV	1012, 1032, 1051, 1052, 1061, 1091, 1147, 1157, 1190, 1197, 1231, 1232, 1357
	SAT	4406
PROTEK	SAT	4406
PROTON	see	HIRSCHMANN
PROVISION	TV	1051, 1052, 1055, 1091, 1111, 1130, 1157, 1160, 1262, 1320
	SAT	4377, 4411
PYE	see	PHILIPS
PYGMY	TV	1298
QUADRAL	TV	1190
	SAT	4450, 4477
QUALCRAFT	TV	1210, 1274
	VCR	2310
QUARTZ	VCR	2356
QUASAR	TV	1119, 1120, 1157, 1186, 1195, 1233, 1274
	VCR	2307
QUEENFID.	VCR	2333
	see	DAEWOO
QUELLE	TV	1003, 1007, 1008, 1012, 1014, 1019, 1026, 1027, 1032, 1046, 1047, 1049, 1051, 1052, 1053, 1054, 1055, 1056, 1061, 1062, 1064, 1065, 1068, 1070, 1072, 1077, 1083, 1087, 1088, 1091, 1107, 1110, 1111,

Brand	Type	Code
		1119, 1120, 1125, 1129, 1132, 1134, 1135, 1136, 1141, 1142, 1143, 1144, 1145, 1154, 1157, 1164, 1167, 1172, 1177, 1178, 1180, 1188, 1189, 1190, 1192, 1195, 1200, 1202, 1204, 1211, 1216, 1217, 1219, 1225, 1231, 1232, 1235, 1238, 1239, 1240, 1245, 1265, 1274, 1287, 1298, 1347, 1350, 1352, 2005
	VCR	1065, 1107, 2302, 2304, 2307, 2310, 2318, 2319, 2323, 2326, 2327, 2330, 2333, 2340, 2342, 2345, 2346, 2348, 2349, 2352, 2354, 2356, 2357, 2362, 2379
	DVD	2001
	SAT	4361, 4395, 4435
	COMBI	2323
QUESTAR	TV	1046, 1047
R. LINE	TV	1051
RADIALVA	TV	1051, 1160
	VCR	2307, 2330, 2345
RADIOLA	see	PHILIPS
RADIO MARELLI	TV	1008, 1012, 1024, 1051, 1052, 1157, 1190, 1195, 1219, 1298
	VCR	2307, 2326, 2356
RADIONETTE	TV	1003, 1021, 1110, 1143
	VCR	2307
RADIOTONE	TV	1051, 1052, 1061, 1091, 1132, 1145, 1147, 1155, 1157, 1197, 1239, 1351, 1357
	SAT	1051
RADIX	SAT	4329, 4386, 4400, 4478
RAINBOW	see	PACE
RAITE	DVD	2023
RANK / RBM	TV	1007, 1012, 1021, 1026, 1039, 1188
	VCR	2330
	DVD	2005
RANK ARENA	VCR	2326
RCA	VCR	2310
RE	SAT	4401
REALISTIC	VCR	2307, 2310, 2319, 2324, 2327, 2333, 2356, 2357
REBOX	SAT	4511
RECOR	TV	1049, 1051, 1052, 1054, 1061, 1062, 1091, 1190
RECORD	TV	1233
RED STAR	TV	1349
	DVD	2079, 2081
	SAT	4420
REDDER	TV	1047, 1233, 1272
REDIFFUS.	TV	1003, 1021
REDO	TV	1157, 1160
	VCR	2343, 2349

Brand	Type	Code
	SAT	4338
REDPOINT	TV	1035
REFLEX	TV	1032, 1051, 1052, 1061, 1177, 1232
REGENTE	TV	1157
REOC	TV	1203
REVOX	TV	1049, 1051, 1062
	VCR	2345
	DVD	2004
REVOY	DVD	2034
REX	see	SELECO
RFT	see	BRUNS
RHINEX	TV	1258
RICHMOND	DVD	2059
RITAR	SAT	4443, 4453
RITZ	TV	1012
RM 2000	TV	1032, 1051, 1052, 1061, 1177, 1232
	VCR	2327
ROADSTAR	TV	1012, 1032, 1042, 1051, 1052, 1061, 1091, 1132, 1150, 1157, 1158, 1177, 1201, 1203, 1206, 1210, 1275, 1287, 1349
	VCR	2307, 2310, 2323, 2327, 2330, 2349, 2350
	DVD	2005, 2007, 2009, 2027, 2034, 2039, 2058, 2071, 2145
	SAT	4390, 4425, 4453, 4367
	COMBI	1042, 1061, 1106, 1157, 1284
ROBERTS	TV	1089
ROBOTR. EL.	TV	1171, 1298
ROCH	SAT	4338
ROSE&HOL.	TV	1079
ROSITA	TV	1157
ROSNER	TV	1231
ROTEL	DVD	2022
ROWA	TV	1032, 1051, 1061, 1091, 1157, 1231
ROWSONIC	TV	1046, 1231
ROYAL	TV	1051, 1091, 1157, 1168, 1190, 1201, 1209, 1210, 1231
	VCR	2330
ROYAL LUX	TV	1201
RUEFACH	see	LENCO
SABA	TV	1010, 1021, 1036, 1039, 1051, 1052, 1061, 1125, 1157, 1160, 1165, 1180, 1194, 1198, 1200, 1202, 1215, 1277, 1289, 1298
	VCR	1284, 2301, 2316, 2322, 2326, 2334, 2348
	DVD	2026, 2057
	SAT	4359, 4385, 4452, 4464, 4490
	COMBI	1041, 1215, 1284
	HIFI	1180
SABRE	see	PACE
SAGEM	TV	1037, 1173
	SAT	4354, 4373, 4500
SAINEL	TV	1012
SAISHO	TV	1008, 1012, 1026, 1052, 1065, 1083,

Brand	Type	Code
		1087, 1091, 1102, 1160, 1203, 1206, 1210, 1231, 1233
	VCR	1107, 2327, 2354
SAITO	see	OCEANIC
SAKAI	TV	1231
SAKIO	TV	1091, 1157, 1160
SAKURA	TV	1157
SALORA	TV	1003, 1006, 1010, 1012, 1013, 1014, 1019, 1021, 1026, 1034, 1051, 1072, 1079, 1111, 1119, 1132, 1134, 1135, 1154, 1183, 1201, 1204, 1206, 1231, 1350
	VCR	2302, 2304, 2314, 2319, 2320, 2326, 2356, 2357
	SAT	4340, 4341, 4355, 4443
SAMBERS	TV	1119, 1120, 1186, 1195, 1233, 1274
	VCR	2307, 2327
	DVD	2066
SAMSUNG	TV	1049, 1052, 1091, 1098, 1119, 1123, 1130, 1132, 1145, 1157, 1161, 1162, 1172, 1173, 1175, 1178, 1183, 1206, 1231, 1232, 1284, 1328, 1356, 1382, 1385, 1405, 1416
	VCR	2302, 2310, 2311, 2352, 2357, 2381
	DVD	2027, 2028, 2052, 2056, 2066, 2097, 2102
	SAT	4322, 4328, 4361, 4397, 4409, 4418, 4422, 4449, 4467, 4481
	COMBI	1281
SAND	TV	1206
SANDOR	see	OCEANIC
SANDRA C.	TV	1231
SANKYO	TV	1051
SANSUI	TV	1032, 1051, 1052, 1054, 1061, 1075, 1079, 1091, 1140, 1157, 1173, 1203, 1209, 1232, 1258, 1287, 1337
	VCR	2314, 2326, 2330, 2354
	DVD	2084
	HIFI	3022
SANWA	see	SANYO
SANY	TV	1194
SANYO	TV	1024, 1046, 1047, 1065, 1069, 1072, 1073, 1079, 1115, 1143, 1145, 1157, 1171, 1172, 1178, 1235, 1298, 1347, 1349
	VCR	2356, 2357, 2379
	DVD	2025, 2056, 2048
SAR	TV	1026, 1052, 1231
SAT	SAT	4481
SAT +	SAT	4327, 4329, 4367, 4471, 4506

Brand	Type	Code
SAT ITALIA	see	WISI
SAT MASTER	SAT	4460
SAT PARTNER	SAT	4403
SATCOM	SAT	4409
SATEC	SAT	4490
SATECO	SAT	4401, 4409, 4430, 4455
SATELLITE	SAT	4440
SATRONIC	TV	1217
SATUM	see	URANYA
SAUBERS	TV	1120
SAVE	see	FORMENTI
SAVEMA	VCR	2307
SAVILLE	see	ORION
SBR	see	PHILIPS
SCANMAGIC	DVD	2009
	see	PHILIPS
SCHAUB LORENZ	TV	1002, 1003, 1006, 1010, 1013, 1014, 1017, 1019, 1021, 1032, 1039, 1051, 1052, 1053, 1061, 1072, 1079, 1091, 1098, 1134, 1145, 1157, 1160, 1177, 1190, 1192, 1203, 1204, 1205, 1209, 1232, 1262, 1287, 1349, 1350, 1393
	VCR	2307, 2326, 2327, 2350, 2356, 2357, 2379
	DVD	2004, 2005, 2083
	SAT	4341, 4355, 4453, 4499
	COMBI	1106
SCHNEID. (F)	see	PHILIPS
SCHNEIDER	TV	1007, 1008, 1012, 1024, 1026, 1027, 1032, 1034, 1049, 1051, 1052, 1061, 1064, 1075, 1130, 1132, 1142, 1145, 1157, 1158, 1173, 1195, 1206, 1210, 1225, 1231, 1262, 1269, 1274, 1347, 1350
	VCR	2307, 2310, 2318, 2319, 2323, 2326, 2327, 2330, 2334, 2340, 2345, 2349, 2350, 2357
	DVD	2001, 2055, 2057, 2058, 2060, 2069, 2080, 2088
	SAT	4367, 4376, 4413, 4453, 4454
	COMBI	1061, 1262
SCOTLAND	TV	1052
	see	FORMENTI
SCOTT	TV	1002, 1051, 1089, 1262
	VCR	2307, 2356
	DVD	2118
SCWEIGER	SAT	4490, 4509
SEARS	see	SANYO
SEAWAY	TV	1061
SECTOR	SAT	4460
SEDEA	SAT	4322, 4323, 4409, 4466, 4508
SEDIP	see	PATHÉ CINEMA
SEELVER	TV	1061
SEEMAN	SAT	4386, 4413

Brand	Type	Code
SEG	TV	1012, 1013, 1032, 1039, 1046, 1049, 1051, 1052, 1061, 1091, 1157, 1171, 1177, 1189, 1195, 1210, 1217, 1225, 1227, 1231, 1232, 1274, 1347
	VCR	2310, 2323, 2327, 2329, 2330, 2350
	DVD	2005, 2023
	SAT	4403, 4409, 4420, 4425
SEI	see	SINUDYNE
SEIGA	see	mitsubishi
SEIKO	TV	1160
	DVD	2005
SELECO	TV	1005, 1011, 1017, 1021, 1027, 1034, 1039, 1047, 1052, 1080, 1081, 1111, 1130, 1132, 1142, 1149, 1154, 1180, 1188, 1192, 1206, 1262, 1287
	VCR	2304, 2307, 2311, 2316, 2323, 2326, 2334, 2340, 2349, 2350, 2357, 2362
	DVD	2005
	SAT	4409, 4453, 4471
	COMBI	1220
SELECT	TV	1032, 1061
SEMP	TV	1077
SENCORA	TV	1157
SENDAY	TV	1051
SENTRA	TV	1034, 1093, 1210
	VCR	2307, 2330
SERINO	TV	1037
SET	TV	1039, 1051, 1052
SETRON	TV	1157
	VCR	2330
SHARP	TV	1046, 1047, 1157, 1214, 1221, 1224, 1231, 1246, 1361
	VCR	2307, 2324, 2332, 2341
	DVD	2041, 2042, 2119, 2138
	COMBI	1214
SHINKO	VCR	2327, 2330
SHINTOM	TV	1052, 1061
	VCR	2327, 2330, 2357
SHINTOSHI	TV	1052
SHIVAKI	TV	1012, 1049, 1052, 1246
	VCR	2307
SHIWAN	see	KAISUI
SHORAI	TV	1083, 1107
	VCR	1107
SHOV	TV	1051, 1052, 1075, 1091, 1157, 1231
SIAREM	TV	1024, 1195, 1298
SICANTIC	see	LUXOR
SICATEL	TV	1012, 1233
SICE	TV	1154
SIDEC	TV	1012
SIEL	TV	1012
SIEMENS	TV	1051, 1137, 1141, 1144, 1154, 1239, 1240, 1244, 1265, 1274
	VCR	1137, 2307, 2310,

Brand	Type	Code
		2319, 2323, 2343, 2344, 2356, 2357, 2362
	SAT	4435
SIERA	TV	1051, 1206
SIESTA	TV	1052, 1145, 1147
SILMA	TV	1052
SILVA	TV	1007, 1046, 1049, 1051, 1052, 1091, 1157, 1274, 1347
	VCR	2307, 2319, 2342
SILVER	TV	1046, 1089, 1091, 1107, 1157, 1173, 1210
	VCR	2356
SIMATEC	see	ORION
SIMKO	VCR	2327
SIMTEL	TV	1052, 1091, 1209, 1210
SINGER	TV	1024, 1051, 1052, 1075, 1080, 1157, 1195, 1206, 1219, 1225, 1227, 1231, 1298
	VCR	2343, 2352, 2356, 2357
SINOTECH	TV	1091, 1190, 1258
SINUDYNE	TV	1009, 1024, 1027, 1051, 1052, 1055, 1056, 1061, 1083, 1087, 1102, 1104, 1107, 1132, 1157, 1182, 1188, 1189, 1195, 1201, 1206, 1210, 1293, 1298, 1337, 1422, 1425, 1430
	VCR	2323, 2340, 2345, 2354
	DVD	2044, 2103, 2117, 2146
	COMBI	1106
SKANTIC	see	LUXOR
SKAY	TV	1209
SKR	SAT	4453
SKY BIRD	SAT	4391, 4401
SKY ENGLAND	SAT	4308
SKY IRELAND	SAT	4308
SKY ITALIA	SAT	4441
SKY LINE	TV	1158, 1231
	SAT	4346
SKYLAB	SAT	4350
SKYMASTER	DVD	2009
	SAT	4329, 4385, 4453, 4477
SKYMAX	SAT	4468
SKYVISION	see	HUTH
SLAVA	TV	1231
SLIMLINE	DVD	2088
SM ELECTR.	DVD	2009
	SAT	4453
SMARAGD	TV	1035
SMART	SAT	4314
SOGERA	TV	1002
SOLARIS	SAT	4369
SOLAVOX	TV	1003, 1014, 1034, 1183
SOMBER	see	CLARIVOX
SONAMEC	VCR	2327
SONICX	TV	1051
SONIKO	TV	1051
SONITRON	TV	1072, 1079, 1231, 1298, 1347, 1349

Brand	Type	Code
	VCR	2307, 2319, 2356
SONNECLAIR	see	DESMET
SONOKO	TV	1051, 1052, 1061, 1091, 1103, 1157, 1209, 1347
	VCR	2330, 2349, 2356
SONOLOR	TV	1003, 1013, 1014, 1019, 1021
	VCR	2324
SONORO	see	AGASHI
SONTEC	TV	1051, 1052, 1145, 1157, 1225
	VCR	2307, 2349
SONY	TV	1046, 1047, 1049, 1052, 1065, 1091, 1148, 1216, 1235, 1236, 1238, 1245, 1256, 1306, 1352, 1356
	VCR	2336, 2337, 2338, 2339, 2369
	DVD	2053, 2086, 2099, 2137
	SAT	4390
	COMBI	1245, 1256, 1362
	HIFI	3062, 3063, 3064
SOUND COLOR	TV	1031, 1032, 1051, 1052, 1061, 1075, 1091, 1158, 1182, 1203, 1206, 1349
SOUND DES.	see	FUNAI
SOUNDMAST	TV	1157
SOUNDVIS.	TV	1195, 1210
SOUNDWAVE	TV	1051, 1091, 1190
SOUTHERN CROSS	TV	1219
SOWTECH	TV	1145
SPECIAL	VCR	2307
SPECTRA	TV	1051, 1091, 1160
SPECTRUM	TV	1288
SPHINX	HIFI	3034
SPORT GEN.	see	FORMENTI
SR	SAT	4413
SSANGYONG	see	SAMSUNG
SSS	see	FUNAI
STAG	see	KAISUI
STANDARD	TV	1002, 1049, 1052, 1157, 1160, 1210, 1219, 1231
	VCR	2349
	DVD	2060
STAR	TV	1051
STAR SAT	SAT	4453
STARLAND	SAT	4328, 4509
STARLINE	TV	1051
STARLITE	TV	1032, 1051, 1052, 1091, 1157
	VCR	2307
STARLUX	TV	1051, 1157, 1231
STARSAT	SAT	4453
START	TV	1052
STASSFURT	see	BRUNS
STELLA	see	CONNEX. SAT
STENWAY	TV	1209, 1210
STERLING	TV	1061
STERN	see	SELECO
STRATO	TV	1091
STREAM	SAT	4441, 4471
STRONG	TV	1160, 4481
	VCR	2327, 2330, 4455
	SAT	4305, 4336, 4339, 4346, 4347, 4356, 4362, 4364, 4367,

Brand	Type	Code
		4376, 4377, 4390, 4393, 4409, 4411, 4432, 4455, 4466, 4494, 4503
STVI	TV	1012, 1231
	SAT	4338, 4390
STZ	VCR	2327
SUNKAI	TV	1037, 1061, 1083, 1102, 1107, 1209, 1267
	VCR	2314, 2354
	DVD	2005, 2058
	SAT	4367
SUNMOONS.	SAT	4356, 4461
SUNNY	TV	1075
SUNSTAR	TV	1051, 1061, 1091, 1157, 1354
	VCR	2327
	SAT	4361, 4420
SUNSTECH	DVD	2060
SUNTRONIC	VCR	2322
SUNWATT	TV	1049
SUNWOOD	TV	1051, 1157
	VCR	2330
SUPERLA	TV	1012
SUPERSON.	TV	1051, 1054, 1075, 1079, 1091, 1157, 1173, 1209
	VCR	2304
SUPERTECH	TV	1007, 1037, 1049, 1051, 1052, 1055, 1061, 1075, 1091, 1157, 1210, 1275
	VCR	2310, 2327
	COMBI	1157
SUPERTONE	see	PATHÉ CINEMA
SUPRA	TV	1037, 1052, 1075, 1157, 1160, 1161, 1275, 1288, 1347
	VCR	2307, 2310, 2327, 2330, 2349
	COMBI	1284, 1288
SUPREME	TV	1037, 1120, 1219
SUTRON	TV	1157
SVA	TV	1258
SWING	TV	1206
SYC LINE	TV	1157, 1231
SYDNEY	TV	1231
SYLVANIA	VCR	2304, 2314, 2327
SYMPHONIC	VCR	2304, 2314, 2327
SYTEL	see	DESMET
SYTONG	TV	1231
TACTIS	VCR	2310
TADISTAR	TV	1012, 1052, 1190
TAISHO	TV	1012
TAKARA	TV	1061
TALENT	TV	1154
TALITA	see	CLARIVOX
TANAKI	TV	1233
TANDBERG	TV	1011, 1027, 1107, 1146, 1188, 1198, 1202, 1295, 1298
TANDY	TV	1026, 1034, 1210, 1231
	VCR	2307, 2330
TANTEC	SAT	4399
TASHIKO	TV	1034, 1039, 1046, 1231, 1347
	VCR	2324, 2327, 2330, 2340, 2345
TATUNG	TV	1049, 1051, 1052, 1054, 1062, 1065, 1172, 1180, 1206,

Brand	Type	Code
		1231, 1287, 1349
	VCR	2326, 2327, 2345
	SAT	4435
TAURO	TV	1287
TCM	TV	1130
TD DESIGN	TV	1062
TEAC	TV	1008, 1049, 1051, 1054, 1157, 1231
	VCR	2326, 2327
	DVD	2001, 2070, 2089
	SAT	4405
TEAM	TV	1209
TEC	see	DUAL-TEC
TECCO	TV	1157, 1198, 1217, 1231
TECHIMAGEN	TV	1132
TECHLINE	TV	1032, 1051, 1052, 1061, 1177, 1195
	VCR	2330
TECHNEMA	see	FORMENTI
TECHNIBOX	SAT	4463
TECHNICA	TV	1157, 1210
TECHNICAL	TV	1061, 2058, 4367
	DVD	2005
TECHNICS	TV	1157, 1164, 1211
	VCR	2333
	DVD	2027
	HIFI	3015, 3073, 3074
TECHNILAND	TV	1049
TECHNISAT	TV	1051, 1132, 1171, 1189, 1247, 1267
	SAT	4372, 4386, 4408, 4422, 4440, 4463
TECHNOL	TV	1049, 1052, 1054, 1062, 1091, 1157, 1160, 1173, 1231
TECHNOM.	SAT	4314
TECHNOSAT	SAT	4352, 4391, 4401
TECHWOOD	TV	1061, 2058, 4367
	DVD	2005, 2059
TECNISON	TV	1052, 1157, 1231
TECO	see	AMSTRAD
TEDELEX	TV	1012, 1049, 1051, 1091, 1157, 1184, 1231, 1258
	VCR	2307
TEF	VCR	2326
TEINEL,SA	TV	1012, 1051
TEKNANT	TV	1051, 1052, 1157, 1209
TEKNIKA	TV	1219
	VCR	2307, 2327
TEKON	TV	1098, 1157
TELE +	SAT	4390
TELEAVIA	see	THOMSON
TELECHROM	TV	1052, 1209
TELECIEL	SAT	4331
TELECO	SAT	4463
TELECOM	SAT	4391, 4401
TELEFAX	TV	1157
TELEFUNKEN	TV	1036, 1039, 1051, 1052, 1157, 1160, 1165, 1180, 1194, 1197, 1198, 1200, 1202, 1215, 1217, 1239, 1257, 1258, 1269, 1289
	VCR	1284, 2301, 2316, 2322, 2323, 2326, 2334, 2348, 2350
	DVD	2001, 2002, 2013, 2020
	SAT	4409, 4430, 4452

Brand	Type	Code
	COMBI	1258, 1284
TELEGAZI	see	FORMENTI
TELEKA	SAT	4339, 4361, 4413, 4418, 4478
TELEKTRON	TV	1157, 1195
TELEMAISTER	see	ORION
TELEMASTER	SAT	4411
TELEOPTA	TV	1157
TELEPAC	TV	1157
TELEPOINT	TV	1051
	VCR	2350
TELERENT	TV	1062
	VCR	2307, 2319, 2326, 2327, 2330, 2333, 2357
TELESERV.	SAT	4390
TELESTAR	TV	1049, 1051, 1052, 1091, 1147, 1155, 1157, 1190, 1349, 1351
TELESYSTEM	SAT	4327, 4329, 4367, 4368, 4376, 4390, 4453
TELETECH	TV	1032, 1051, 1061, 1157, 1217
	VCR	2330
	SAT	4368
TELETON	TV	1005, 1026, 1027, 1046, 1142, 1188, 1192, 1231
TELEVES	SAT	4511
TELEVIDEON	VCR	2356
TELEWIRE	SAT	4314, 4391, 4401
TELEXA	TV	1195
TELKOM	TV	1051, 1052
TELRA	TV	1039, 1052, 1165, 1180, 1349, 1351
TEMCO	see	SHORAI
TEMPEST	TV	1157, 1210, 1231
	VCR	2310
TENNESSEE	TV	1051
TENOSAL	VCR	2330
TENSAI	TV	1002, 1012, 1032, 1049, 1051, 1052, 1061, 1075, 1107, 1110, 1130, 1132, 1143, 1157, 1160, 1175, 1182, 1186, 1195, 1210, 1219, 1231, 1274, 1287
	VCR	2307, 2310, 2319, 2327, 2329, 2330
	DVD	2038
	COMBI	1157, 2327
TENSON	TV	1002, 1157
TERMAL	SAT	4430, 4453, 4468
TESLA	TV	1012, 1037, 1049, 1051, 1052, 1061, 1075, 1123, 1130, 1132, 1188, 1206, 1210, 1233, 1287, 1298, 1350
TETRAN	TV	1002, 1012
TEVION	TV	1032, 1061, 1130, 1203, 1351
	VCR	2350
	DVD	2057
TEXET	TV	1231
THOMAS	TV	1173
THOMSON	TV	1012, 1035, 1036, 1051, 1120, 1125, 1165, 1180, 1194,

Brand	Type	Code
		1198, 1200, 1202, 1215, 1224, 1257, 1277, 1289, 1298
	VCR	2301, 2316, 2322, 2326, 2334, 2348
	DVD	2026, 2057, 2129, 2131
	SAT	4371, 4390, 4430, 4441, 4452, 4453, 4464, 4490, 4500
	COMBI	1041, 1215, 1246, 1284, 2026
THORENS	SAT	4406
THORN	TV	1003, 1010, 1012, 1015, 1017, 1019, 1021, 1026, 1027, 1034, 1036, 1046, 1047, 1049, 1051, 1052, 1054, 1065, 1068, 1069, 1070, 1071, 1072, 1073, 1077, 1079, 1091, 1093, 1110, 1111, 1114, 1125, 1130, 1132, 1133, 1143, 1144, 1154, 1157, 1164, 1165, 1172, 1178, 1180, 1194, 1197, 1198, 1206, 1211, 1215, 1216, 1231, 1232, 1233, 1235, 1238, 1245, 1246, 1257, 1279, 1287, 1347, 1352, 2348
	VCR	2307, 2316, 2322, 2326, 2327, 2330, 2334, 2340, 2348, 2352, 2356, 2357, 2379
	SAT	4395, 4435, 4464, 4490, 4507
THUNDERM.	SAT	4386, 4390, 4399, 4419, 4468, 4498, 4504
TICSONIC	TV	1231
TMX	SAT	4322, 4390, 4419, 4504
TOBISHI	TV	1091, 1098, 1107, 1157, 1210, 1231
TOBO	TV	1091, 1157
TOGOSHI	TV	1047
TOKAI	TV	1002, 1039, 1051, 1061, 1091, 1157
	VCR	2307, 2330
	DVD	2023
TOKIWA	see	TOKAI
TOKO	see	KATHREIN
TOKYO	TV	1098, 1209
TOMASHI	see	KAISUI
TOMITA	TV	1231
TONNA EL.	SAT	4401, 4430
TOP VISION	TV	1012, 1039, 1052, 1147, 1186
TOPFIELD	SAT	4322, 4442
TOPLINE	TV	1032, 1061
TOPSHOW	TV	1091, 1258
TORRE	see	THOMSON
TOSHIBA	TV	1046, 1047, 1048, 1049, 1054, 1061, 1070, 1077, 1088, 1093, 1141, 1213, 1231, 1276
	VCR	2326, 2352

Brand	Type	Code
	DVD	2012
	SAT	4306, 4464
TOTEVISION	VCR	2307, 2310
TOWADA	TV	1012, 1195
	VCR	2327, 2329, 2330
TOWIKA	VCR	2330
TOYOSI	TV	1233
TPS	SAT	4373
TRACK	VCR	2302
TRANS CONT.	see	PRANDONI
TRANSONIC	TV	1049, 1052, 1091, 1155
	VCR	2304
TREVI	TV	1012, 1046, 1047, 1157, 1209
	DVD	2001, 2039, 2057, 2060
TRIAD	TV	1052, 1233
	SAT	4462, 4481
TRIASAT	see	WISI
TRIAx	SAT	4372, 4390, 4435, 4440, 4463, 4508
TRIDENT	TV	1231
TRILUX	TV	1032, 1051, 1130, 1147, 1228
TRISTAR	TV	1091, 1210
TRIUMPH	TV	1062, 1120
TRIVISION	TV	1157
TSOSHI	see	KAISUI
TTR	VCR	2326
TV CABO	SAT	4316, 4369, 4373
TV STAR	TV	1026
TVD	TV	1061
TWINNER	VCR	2330
TWINSAT	SAT	4321, 4399, 4404, 4430, 4447
UHER	TV	1002, 1026, 1034, 1051, 1052, 1061, 1062, 1120, 1142, 1149, 1186, 1192, 1195
	VCR	2307, 2310, 2318, 2326, 2345, 2354
ULTRAVISION	TV	1072, 1233
ULTRAVOX	TV	1015, 1024, 1034, 1051, 1052, 1055, 1160, 1195, 1225, 1231, 1298
	VCR	2349, 2356
	SAT	4391, 4397, 4401
UNIC RADIO	TV	1012, 1039, 1051, 1052, 1145, 1231, 1233, 1347
	VCR	2327, 2330
UNIDEN	SAT	4470
UNIMOR	TV	1002, 1051, 1142, 1145, 1147
UNITECH	VCR	2310
UNITED	TV	1032, 1061, 1145, 1147, 1158, 1203, 1287, 2058, 4367
	VCR	2343, 2349
	DVD	2001, 2005, 2024, 2034, 2058, 2059, 2081, 2091
	COMBI	1106
UNITOR	SAT	4350, 4403
UNITRON	TV	1303
UNITRONIC	DVD	2041
UNIVERSUM	see	QUELLE
UNIVOX	TV	1003, 1012, 1051, 1052, 1219, 1233, 1298

Brand	Type	Code
UNK	TV	1012, 1032, 1051, 1052, 1061, 1172, 1203
URANIA	see	SAMBERS
URANYA	TV	1002, 1051, 1052, 1120, 1145, 1157, 1160, 1186, 1195
	VCR	2307, 2353, 2356
UTAX	TV	1157, 1231
V-TECH	SAT	4411, 4454, 4481
VANGUARD	TV	1002, 1026, 1157, 1347
VARIOSAT	see	WISI
VASILINEC	TV	1157
VECO	TV	1052, 1157
VECT. RES	VCR	2310, 2342
	SAT	4462
VENTANA	TV	1061
	SAT	4468
VESTEL	TV	1007, 1008, 1012, 1026, 1032, 1051, 1052, 1061, 1132, 1145, 1177, 1217, 1232, 1279, 1423
	DVD	2005, 2009
VEXA	TV	1012, 1052, 1132, 1157, 1209, 1231
	VCR	2349, 2350
VIA	SAT	4371, 4451, 4500
VICEROY	TV	1082, 1091, 1231, 1274
VICTOR	VCR	2316, 2326
VIDAR	VCR	2356
VIDECON	TV	1049
VIDEO ELECT. CLUB	VCR	2356
VIDEO TECHNIK	VCR	2330
VIDEOLAGIC	TV	1091, 1210, 1231
VIDEOMAC	TV	1091, 1231
VIDEON	TV	1051
VIDEOSAT	TV	1217, 1225
VIDEOSYST.	TV	1052
VIDEOTON	TV	1006, 1007, 1008, 1012, 1020, 1039, 1049, 1051, 1052, 1061, 1072, 1190, 1194, 1219, 1231, 1233, 1262, 1289
	DVD	2005, 2009, 2058
	SAT	4367
VIDESON	TV	1012
VIDIKRON	TV	1002, 1046, 1049, 1157, 1186, 1195
VIDION	TV	1157
	VCR	2330, 2349, 2350, 2356, 2357
VIDITAL	TV	1091
	VCR	2349
VISIOLA	see	PATHE CINEMA
VISION 2000	TV	1002, 1051, 1052, 1061, 1091, 1157
VISIONIC	SAT	4322, 4323, 4353, 4466, 4507
VISIONPLUS	SAT	4479
VISIOSAT	SAT	4321, 4334, 4401, 4403, 4414, 4419, 4466, 4509
VISTA	see	THORN
VISTAR	TV	1014
VORTEC	TV	1051
	SAT	4397, 4409, 4418, 4422

Brand	Type	Code
VOXSON	TV	1034, 1091, 1120, 1225, 1227, 1298
WAGNER	TV	1002, 1003, 1051, 1052, 1195, 1225
WAITEC	DVD	2009, 2057
WALKIE	TV	1142, 1188
WALKVISION	TV	1061, 2058, 4367
	DVD	2005
WALTHAM	see	VIDEOTON
WATSON	TV	1002, 1024, 1032, 1034, 1049, 1051, 1052, 1061, 1091, 1151, 1155, 1157, 1177, 1182, 1210, 1239
	VCR	2323
WATT RADIO	TV	1007, 1008, 1024, 1027, 1052, 1145, 1157, 1186, 1190, 1195, 1219, 1231, 1233, 1275
	VCR	2349
WEGA VIS.	TV	1046
	VCR	1065
WEGAVOX	TV	1007, 1032, 1049, 1051, 1061, 1091, 1123, 1147, 1157, 1158, 1189, 1190, 1203, 1217, 1225, 1227, 1350
WELLFUND	TV	1209
WELLINGTON	TV	1061
	DVD	2005, 2058
	SAT	4367
WELTBlich	TV	1002, 1051, 1052, 1275, 1287
	VCR	2307, 2349
WESDER	DVD	2034
WEST POINT	VCR	2311
WESTON	TV	1039, 1209
WESTWOOD	TV	1061
	DVD	2005
WEVASAT	SAT	4462
WHARFED.	TV	1206
WHITE WESTHING.	TV	1002, 1012, 1024, 1026, 1039, 1051, 1052, 1091, 1120, 1142, 1145, 1149, 1157, 1188, 1190, 1192, 1195, 1209, 1231, 1262, 1287
	VCR	2307, 2330, 2349, 2356, 2357
WILSON	TV	1061
WINDSOR	TV	1032, 1052, 1061
	DVD	2005, 2058
	SAT	4367
WINDSTAR	see	THORN
WINERSAT	SAT	4403, 4414
WINSTON	TV	1051, 1052, 1061, 1157, 1209
WINTERNITZ	TV	1032, 1157, 1159, 1160
	SAT	4395, 4462
WISI	SAT	4372, 4386, 4435, 4454, 4481, 4482
WITTENB.	SAT	4490
WORLD TECH	TV	1052
WORLDSAT	SAT	4321, 4356, 4399, 4404, 4430, 4447
WORLDVIEW	TV	1049, 1052, 1075, 1157, 1173
WORTEN	TV	1037, 1188

Brand	Type	Code
WREMEN	TV	1186
X PLAYER	DVD	2059
X SAT	SAT	4311, 4430, 4480
XCELLENT	TV	1051, 1052
XCOM	SAT	4430, 4480
XL-ELETTR.	DVD	2061
XONYCS	TV	1051, 1142
	VCR	2330, 2349
XRIPTON	TV	1051, 1190
XTREME	SAT	4303
YAMADA	DVD	2059, 2098
YAMAHA	VCR	2326, 2342
	DVD	2027, 2037
	HIFI	3064
YAMAKAWA	DVD	2023, 2142
YAMISHI	TV	1209
	VCR	2330
YAMO	TV	1210
YOCAN	VCR	2330
YOKO	TV	1012, 1026, 1039, 1051, 1052, 1072, 1091, 1093, 1136, 1157, 1160, 1198, 1210, 1217, 1219, 1225, 1231, 1274
	VCR	2307, 2310, 2327, 2329, 2330
YORK	TV	1210
YOSHITA	TV	1052
	VCR	2330
YOTAKA	TV	1052
YUMATU	TV	1052, 1075, 1091, 1157, 1190
ZAMPA	TV	1021
ZANELA	TV	1047, 1221, 1224, 1246
	VCR	2327, 2330
ZANUSSI	see	SELECO
ZEHNDER	SAT	4329, 4361, 4403, 4420, 4454, 4481
ZENOR	TV	1079
ZEPHYR	VCR	2307, 2349
ZIRWATEL	TV	1002, 1051, 1142, 1157, 1192, 1215, 1245
ZODIAC	SAT	4310, 4353, 4368, 4370, 4433, 4460, 4472, 4478
ZOPPAS	see	SELECO